



BSP ŽENSKI 60° KONUSNI – BS5200 (žicom ubodena matica)

NP	"	Navoj	Ključ H1	Ključ H2
5	3/16	1/8 " - 28	-	14
6	1/4	1/8 " - 28	-	14
8	5/16	1/4 " - 19	-	19
10	3/8	1/4 " - 19	-	19
12	1/2	3/8 " - 19	-	22
12	1/2	5/8 " - 14	-	28
12	1/2	3/4 " - 14	-	32
16	5/8	5/8 " - 14	-	28
16	5/8	3/4 " - 14	-	32
20	3/4	3/4 " - 14	-	32
20	3/4	1 " - 11	-	38
25	1	1 " - 11	-	38




BSP ŽENSKI 60° KONUSNI – BS5200 (pasujuća matica)

NP	"	Navoj	Ključ H1	Ključ H2
5	3/16	1/4 " - 19	-	19
6	1/4	1/4 " - 19	-	19
6	1/4	3/8 " - 19	-	22
8	5/16	3/8 " - 19	-	22
10	3/8	3/8 " - 19	-	22
10	3/8	1/2 " - 14	-	27
12	1/2	1/2 " - 14	-	27




45° BSP ŽENSKI 60° KONUSNI – BS5200 (žicom ubodena matica)

NP	"	Navoj	Ključ H1	Ključ H2
5	3/16	1/8 " - 28	-	14
6	1/4	1/8 " - 28	-	14
12	1/2	5/8 " - 14	-	28
12	1/2	3/4 " - 14	-	32
16	5/8	5/8 " - 14	-	28
16	5/8	3/4 " - 14	-	32
20	3/4	3/4 " - 14	-	32
20	3/4	1 " - 11	-	38
25	1	1 " - 11	-	38




45° BSP ŽENSKI 60° KONUSNI – BS5200 (pasujuća matica)

NP	"	Navoj	Ključ H1	Ključ H2
6	1/4	1/4 " - 19	-	19
6	1/4	3/8 " - 19	-	22
8	5/16	3/8 " - 19	-	22
10	3/8	3/8 " - 19	-	22
10	3/8	1/2 " - 14	-	27
12	1/2	1/2 " - 14	-	27




90° BSP ŽENSKI 60° KONUSNI – BS5200 (žicom ubodena matica)

NP	“	Navoj	Ključ H1	Ključ H2
5	3/16	1/8 “ - 28	14	-
6	1/4	1/8 “ - 28	14	-
6	1/4	1/4 “ - 19	19	-
6	1/4	3/8 “ - 19	22	-
8	5/16	3/8 “ - 19	22	-
10	3/8	3/8 “ - 19	22	-
10	3/8	1/2 “ - 14	27	-
12	1/2	3/8 “ - 19	22	-
12	1/2	1/2 “ - 14	27	-
12	1/2	5/8 “ - 14	30	-
12	1/2	3/4 “ - 14	32	-
16	5/8	5/8 “ - 14	30	-
16	5/8	3/4 “ - 14	32	-
20	3/4	3/4 “ - 14	32	-
20	3/4	1 “ - 11	41	-
25	1	1 “ - 11	41	-
25	1	1.1/4 “ - 11	50	-
32	1.1/4	1.1/4 “ - 11	50	-
38	1.1/2	1.1/2 “ - 11	55	-
50	2	2 “ - 11	70	-




90° BSP ŽENSKI 60° KONUSNI – BS5200 (pasujuća matica)

NP	“	Navoj	Ključ H1	Ključ H2
6	1/4	1/4 “ - 19	-	19
6	1/4	3/8 “ - 19	-	22
8	5/16	3/8 “ - 19	-	22
10	3/8	3/8 “ - 19	-	22
10	3/8	1/2 “ - 14	-	27
12	1/2	1/2 “ - 14	-	27




BSP „O – RING“ ŽENSKI 60° KONUSNI – BS5200 (pasujuća matica)

NP	“	Navoj	Ključ H1	Ključ H2
6	1/4	1/4 “ - 19	-	19
10	3/8	3/8 “ - 19	-	22
12	1/2	1/2 “ - 14	-	27
16	5/8	5/8 “ - 14	-	28
20	3/4	3/4 “ - 14	-	32
25	1	1 “ - 11	-	38
25	1	1.1/4 “ - 11	-	50
32	1.1/4	1.1/4 “ - 11	-	50
32	1.1/4	1.1/2 “ - 11	-	60
38	1.1/2	1.1/2 “ - 11	-	60
38	1.1/2	2 “ - 11	-	70
50	2	2 “ - 11	-	70




**45° BSP „O – RING“ ŽENSKI 60° KONUSNI – BS5200
(žicom ubodena matica)**

NP	“	Navoj	Ključ H1	Ključ H2
6	1/4	1/4 “ - 19	-	19
10	3/8	3/8 “ - 19	-	22
12	1/2	1/2 “ - 14	-	27
16	5/8	5/8 “ - 14	-	28
20	3/4	3/4 “ - 14	-	32
25	1	1 “ - 11	-	38
32	1.1/4	1.1/4 “ - 11	-	50
38	1.1/2	1.1/2 “ - 11	-	60
50	2	2 “ - 11	-	70




**90° BSP „O – RING“ ŽENSKI IZ JEDNOG KOMADA ss
KOLENO 60° KONUSNI – BS5200 (žicom ubodena matica)**

NP	“	Navoj	Ključ H1	Ključ H2
6	1/4	1/4 “ - 19	-	28
10	3/8	3/8 “ - 19	-	32
12	1/2	1/2 “ - 14	-	38
16	5/8	5/8 “ - 14	-	50
20	3/4	3/4 “ - 14	-	60
25	1	1 “ - 11	-	70




90° BSP „O – RING“ ŽENSKI 60° KONUSNI – BS5200 (žicom ubodena matica)

NP	“	Navoj	Ključ H1	Ključ H2
6	1/4	1/4 “ - 19	-	19
10	3/8	3/8 “ - 19	-	22
12	1/2	1/2 “ - 14	-	27
16	5/8	5/8 “ - 14	-	28
20	3/4	3/4 “ - 14	-	32
25	1	1 “ - 11	-	38
25	1	1.1/4 “ - 11	-	50
32	1.1/4	1.1/4 “ - 11	-	50
32	1.1/4	1.1/2 “ - 11	-	60
38	1.1/2	1.1/2 “ - 11	-	60
38	1.1/2	2 “ - 11	-	70
50	2	2 “ - 11	-	70




BSP ŽENSKI RAVNO SEDIŠTE – (žicom ubodena matica)

NP	“	Navoj	Ključ H1	Ključ H2
12	1/2	3/4 “ - 14	-	32
16	5/8	5/8 “ - 14	-	28
16	5/8	3/4 “ - 14	-	32
20	3/4	3/4 “ - 14	-	32
20	3/4	1 “ - 11	-	38
25	1	1 “ - 11	-	38




BSP ŽENSKI RAVNO SEDIŠTE – (pasujuća matica)

NP	“	Navoj	Ključ H1	Ključ H2
6	1/4	1/4 “ - 19	-	19
10	3/8	3/8 “ - 19	-	22
10	3/8	1/2 “ - 14	-	27
12	1/2	1/2 “ - 14	-	27



BSP MUŠKI PARALELNI 60° KONUSNO SEDIŠTE – BS5200

NP	"	Navoj	Ključ H1	Ključ H2
5	3/16	1/8 " - 28	14	-
6	1/4	1/8 " - 28	14	-
6	1/4	1/4 " - 19	19	-
6	1/4	3/8 " - 19	22	-
8	5/16	3/8 " - 19	22	-
10	3/8	3/8 " - 19	22	-
10	3/8	1/2 " - 14	27	-
12	1/2	3/8 " - 19	22	-
12	1/2	1/2 " - 14	27	-
12	1/2	5/8 " - 14	30	-
12	1/2	3/4 " - 14	32	-
16	5/8	5/8 " - 14	30	-
16	5/8	3/4 " - 14	32	-
20	3/4	3/4 " - 14	32	-
20	3/4	1 " - 11	41	-
25	1	1 " - 11	41	-
25	1	1.1/4 " - 11	50	-
32	1.1/4	1.1/4 " - 11	50	-
38	1.1/2	1.1/2 " - 11	55	-
50	2	2 " - 11	70	-



BSP MUŠKI RAVNO SEDIŠTE

NP	"	Navoj	Ključ H1	Ključ H2
6	1/4	1/4 " - 19	19	-
10	3/8	3/8 " - 19	22	-
10	3/8	1/2 " - 14	27	-
12	1/2	1/2 " - 14	27	-
20	3/4	3/4 " - 14	32	-
25	1	1 "	41	-