




















## Pneumatski priključci - GU serija

|   |   |  |   |   |   |
|---|---|--|---|---|---|
|  |  |  |  |  |   |
| GU 21-13-06   | GU 21-15-06<br>GU 21-15-08  | GU 21-22-06  | GU 21-24-06<br>GU 21-24-08  | GU 26-11-00-38  |   |
|  |  |  |  |  |  |
| GU 21-13-06   | GU 21-15-06<br>GU 21-15-08  | GU 21-13-06  | GU 21-15-06<br>GU 21-15-08  | GU 21-13-06   | GU 21-15-06<br>GU 21-15-08  |









Oznake u nazivu priključaka: GU 21-13-06

| GU     | 21      | 13            | 06    |
|--------|---------|---------------|-------|
| Seriya | Artikal | Prečnik creva | Navoj |

## Pneumatski priključci - MA serija

|  |  |  |  |  |  |  |  |
|---|---|---|--|---|---|---|---|
| MA 11-04-14   | MA 12-04-14   | MA 14-04-14   | MA 16-04-14  | MA 18-04-M5   | MA 19-04-14   | MA 20-04-14   | MA 22-04-M5   |
| MA 11-04-18   | MA 12-04-18   | MA 14-04-18   | MA 16-04-18  | MA 18-06-14   | MA 19-04-18   | MA 20-04-18   | MA 22-06-14   |
| MA 11-06-14   | MA 12-04-M5   | MA 14-06-14   | MA 16-04-M5  | MA 18-06-18   |   | MA 20-06-14   | MA 22-06-18   |
| MA 11-06-18   | MA 12-04-M6   | MA 14-06-18   | MA 16-04-M6  | MA 18-06-M5   |   | MA 20-06-18   | MA 22-06-M5   |
| MA 11-08-14   | MA 12-06-12x1.25  | MA 14-08-14   | MA 16-06-12x1.25   | MA 18-08-14   |   | MA 20-08-14   | MA 22-08-14   |
| MA 11-08-18   | MA 12-06-12x1.5   | MA 14-08-18   | MA 16-06-12x1.5  | MA 18-08-18   |   | MA 20-08-18   | MA 22-08-18   |
| MA 11-08-38   | MA 12-06-14   | MA 14-10-14   | MA 16-06-14  | MA 18-10-14   |   | MA 20-08-38   | MA 22-10-14   |
| MA 11-10-12   | MA 12-06-18   | MA 14-10-38   | MA 16-06-18  | MA 18-10-38   |   | MA 20-10-14   | MA 22-10-38   |
| MA 11-10-14   | MA 12-06-M5   |   | MA 16-06-M5  |   |   | MA 20-10-38   |   |
| MA 11-10-38   | MA 12-06-M6   |   | MA 16-06-M6  |   |   | MA 20-12-12   |   |
| MA 11-12-12   | MA 12-08-14   |   | MA 16-08-14  |   |   | MA 20-12-38   |   |
|   | MA 12-08-18   |   | MA 16-08-18  |   |   |   |   |
|   | MA 12-08-38   |   | MA 16-08-38  |   |   |   |   |
|   | MA 12-10-12   |   | MA 16-10-14  |   |   |   |   |
|   | MA 12-10-14   |   | MA 16-10-38  |   |   |   |   |
|   | MA 12-10-18   |   | MA 16-12-12  |   |   |   |   |
|   | MA 12-10-38   |   | MA 16-12-14  |   |   |   |   |
|   | MA 12-12-12   |   | MA 16-12-38  |   |   |   |   |
|   | MA 12-12-14   |   |  |   |   |   |   |
|   | MA 12-12-38   |   |  |   |   |   |   |





## Pneumatski priključci - MA serija

|   |   |  |  |   |   |   |   |
|---|---|--|--|---|---|---|---|
|  |                      |   |  |  |  |  |  |
| MA 24-08-14   | MA 25-03-04<br>MA 25-04-06<br>MA 25-04-08<br>MA 25-06-04<br>MA 25-06-08<br>MA 25-08-06<br>MA 25-08-10 | MA 26-03-03<br>MA 26-04-04<br>MA 26-06-04<br>MA 26-06-06<br>MA 26-08-06<br>MA 26-08-08<br>MA 26-10-08<br>MA 26-10-10<br>MA 26-12-12<br>MA 26-14-14 | MA 27-04-04<br>MA 27-06-06<br>MA 27-08-08<br>MA 27-10-10                           | MA 28-06-06<br>MA 28-08-08<br>MA 28-10-10<br>MA 28-12-12<br>MA 28-14-14             | MA 29-04-06<br>MA 29-06-08<br>MA 29-08-10<br>MA 29-10-12<br>MA 29-12-14             | MA 30-00-12<br>MA 30-00-14<br>MA 30-00-18<br>MA 30-00-38<br>MA 30-00-M5             | MA 37-04-04<br>MA 37-06-06<br>MA 37-08-08   |

Oznake u nazivu priključaka: MA 24-08-14

| MA     | 24      | 08            | 14    |
|--------|---------|---------------|-------|
| Serija | Artikal | Prečnik creva | Navoj |


## Pneumatski priključci - MV serija

|   |   |   |   |
|---|---|---|---|
|  |  |  |  |
| MV 24-00-12   | MV 25-00-12<br>MV 25-00-14<br>MV 25-00-18<br>MV 25-00-38                          | MV 34-04-04<br>MV 34-06-06<br>MV 34-08-08   | MV 41-06-18<br>MV 41-08-18<br>MV 41-10-14   |

Oznake u nazivu priključaka: MV 24-00-12

|               |           |               |           |
|---------------|-----------|---------------|-----------|
| <b>MV</b>     | <b>24</b> | <b>00</b>     | <b>12</b> |
| Serijski broj | Artikal   | Prečnik creva | Navoj     |

## Pneumatski priključci - RA serija



|  |              |   |  |
|--|--------------|---|--|
| RA 011-12-12<br>RA 011-14-12<br>RA 011-14-14<br>RA 011-14-38<br>RA 011-18-14<br>RA 011-18-18<br>RA 011-18-38<br>RA 011-38-12<br>RA 011-M5-18<br>RA 011-M5-M5 | RA 012-34-34 | RA 013-12<br>RA 013-14<br>RA 013-18<br>RA 013-38<br>RA 013-M5 | RA 015-14-12<br>RA 015-14-38<br>RA 015-18-12<br>RA 015-18-14<br>RA 015-18-38<br>RA 015-38-12<br>RA 015-M5-18 |
|--|--------------|---|--|

Oznake u nazivu priključaka: RA 011-12-12

| RA     | 011     | 12    | 12    |
|--------|---------|-------|-------|
| Seriya | Artikal | Navoj | Navoj |